Appendix C

Meteorological Station Maintenance

- RM Young 05305 Wind Monitor-AQ: inspect propeller and vertical shaft bearings semi-annually and replace at least annually.
- <u>Model SP-LITE Pyranometer</u>: routine cleaning in the field, no special requirements.
- <u>Texas Instruments TE525WS 8-inch Rain Gage</u>: periodically check that gage is level and tipping bucket is operable. Routine cleaning of snowfall adapter in the field.
- <u>Vaisala HMP45C Temperature/Relative Humidity Probe</u>: routine cleaning in the field.
- <u>Electrical Equipment</u>: keep free of moisture. Check all wiring connections periodically.
- <u>Batteries</u>: periodically check charge, change when necessary.